



# DOCUMENT CAMERA

Access the document camera by unlatching the side compartment of the podium.



## POWER ON/OFF

A visual indicator is located near the power button - a red light means the power is off and a blue light means the power is on.



## ZOOM

Control the zoom of the camera by pressing the **Zoom +** and **Zoom -** buttons.



## DOCUMENT LIGHTS

Press the **Lamp** button to control the light intensity - bright, dim, and off.



## FREEZE

Press the **Freeze** button to freeze and unfreeze an image on the screen.

## AUTO

### AUTO TUNE

Press the **Auto Tune** button to optimize the image. This includes color correcting and focusing the lens.

## FOCUS

### FOCUS

The lens should automatically focus, but if it doesn't, press the **Focus** button located on the gooseneck lens.