



use standard 0805 resistors with 125 mW to get a 6,25 W dummy load  
use Digkey P16057CT-ND resistors with 500 mW to get a 25 W dummy load

attenuator configuration is shown.  
do not populate CN2 and change R15 to 100R and R51 to 0R  
if you want to use it as a dummy load

This documentation describes Open Hardware and is licensed under the CERN OHL v. 1.2.  
You may redistribute and modify this documentation under the terms of the CERN OHL v.1.2. (<http://ohw.org/cernohl>).  
This documentation is distributed WITHOUT ANY EXPRESS OR IMPLIED WARRANTY, INCLUDING OF MERCHANTABILITY, SATISFACTORY  
QUALITY AND FITNESS FOR A PARTICULAR PURPOSE. Please see the CERN OHL v.1.2 for applicable conditions

**generationmake**

Sheet: /  
File: DummyLoad.sch

**Title: ArduTrx Dummy Load**

Size: A4 | Date: 2019-07-24 | **Rev: 1.1**

KiCad E.D.A. kicad 5.0.2-6ee76a070ubuntu18.04.1 | Id: 1/1