



Pun Pod for the FT Pun Jet




3mm foamboard

black = cut

 remove foam

--- fold here



3 mm plywood

black = cut

..... pun pods outline

Use a Bar-BQ Skewer to fix the pod in the Jet!

Print it out with 100%!

by Ninsei

Airc Pirates—the sky is our ocean!

Thank you Flight Test for the Pun Jet!