



FUNCTION KEYS: HELP, START, SELECT, OPTION and RESET  
Those keys should be reused from original



EXTRA FUNCTION KEYS (as Atari 1200XL) F1, F2, F3, F4



MountingHole H4  
MountingHole H3  
MountingHole H2  
MountingHole H1

CHERRY MX BASED  
FOR ANY ATARI XE LINE OF COMPUTERS  
A PCB KEYBOARD AS DROP IN REPLACEMENT

Sheet: /  
File: A130XE\_KB\_MX.sch

# Title: ATARI XE KEYBOARD PCB

Size: A3	Date: 2020-10-10	Rev: 0.2
KiCad E.D.A.	kiCad 5.0.2+dfsg1-1	Id: 1/1

88