



CALYPTO-PERKINS

Smart Soap Dispenser



NO-DRIP VALVE

When Dispensing, The Flexible Silicone Valve Springs Open For A Quick, Steady Flow, then Snaps Shut To Create A Seal Preventing Messy Drips.



SPEED DISPENSE

The unique gear design in our high-efficiency pump is engineered to maximize forward flow and minimize backflow for faster, more consistent dispensing — in just 0.2 seconds.



THE PERFECT SOAP

The perfect consistency for sensor pumps no clogs or drips. Dispenses the correct amount quickly and consistently.

FEATURES

Touch-Free Sensor Soap Pump

Perfect for your kitchen or bathroom, our automatic sensor soap pump is the most efficient way to wash your hands — no germs or smudges left behind. Its compact size is perfect for small sinks or countertops.

Quick, Precise Dispensing With No Drips

Our touch-free sensor soap pump has a precise trigger zone for accurate, high-speed activation and the high-efficiency pump dispenses soap in just 0.2 seconds. Then its flexible silicone valve snaps shut to create a seal preventing messy drips.

Volume Control

Easy-access control buttons make it easy to adjust the volume of soap to exactly what you prefer.

Easy Opening for Soap Refills

A wide refill opening makes refills fast, easy and spill-free.

Energy Efficient


Lasts up to 1 year with 4 alkaline AA batteries (not included).

SPECIFICATIONS


| | |
|--------------------|---|
| Product Dimensions | 2.8 x 6.9 x 5.7 inches |
| Item Weight | 11.2 ounce |
| Shipping Weight | 1.5 pounds (View shipping rates and policies) |
| Department | unisex |
| Manufacturer | simplehuman |
| ASIN | B00A20VOPI |
| Item model number | ST1023 |
| Batteries | 4 AA batteries required. |

How to set "Out of Soap Alerts"


- You Can Easily Replace The Liquid Soap Smart Soap Dispenser Will Alert You. It's Time To Refill The Soap
- Switch On: Press And Hold The “+” Button For 1.2 Seconds. The Red Light Will Flash Twice
- Switch Off: Press And Hold The “-” Till Indicate Light Off




DEFAULT CREDENTIALS



① Username is Admin




② Password is Password



③ Easily get Notification & order soap

HOW TO RESET THE DEVICE TO FACTORY SETTINGS

① Go To App Manager



② Select The App



③ Reset The App Factory

