


USB-C KIT FOR NINTENDO 2DS NINTENDO NEW 2DS XL



NINTENDO 2DS USB-C KIT

[HTTPS://SHOP.GILTESA.COM/PRODUCT/NINTENDO-2DS-USB-C-KIT](https://shop.giltesa.com/product/nintendo-2ds-usb-c-kit)

**PLEASE READ THROUGH THESE INSTRUCTIONS
ENTIRELY BEFORE ATTEMPTING TO INSTALL**

**WARNING: IF YOU ARE NOT COMFORTABLE WITH
SOLDERING, OR PERFORMING ANY STEP IN THIS
GUIDE, DO NOT PERFORM THE INSTALL YOURSELF.
FIND SOMEONE WHO IS COMFORTABLE TO DO IT FOR
YOU.**

INDEX

DESCRIPTION	4
FEATURES	4
INCLUDED	4
RECOMMENDED / REQUIRED [NOT INCLUDED]	5
BOARD DETAILS.....	6
INSTALLATION STEPS	7
PRE INSTALLATION STEPS.....	7
1. DISASSEMBLY THE NINTENDO 2DS	7
INSTALLATION STEPS.....	13
1. PROTECT THE NEAREST COMPONENTS.....	13
2. REMOVE UNNECESSARY COMPONENTS	13
3. CLEAN THE BOARD.....	14
4. INSTALLATION OF THE USB-C BOARD.....	15
5. CUTTING THE PLASTIC SHELL	19
6. FINISHING THE INSTALLATION.....	20

DESCRIPTION

The **Nintendo 2DS: USB-C Kit** is a board that allows to replace the original charging connector for a modern and standard **USB-C**.

If your original connector is too old or damaged and you need a new one, or if you would like to charge your Nintendo 2DS with a standard **USB-C charger**, like the charger of your **Nintendo Switch**, phone, laptop, you can with this kit.

This board is compatible with these two models:

- Nintendo 2DS
- Nintendo New 2DS XL

FEATURES

- Charging your Nintendo with:
 - USB power banks
 - USB-A chargers
 - USB-C chargers
 - USB-C PD chargers (normal speed, not fast)
 - USB-A to USB-C cables
 - USB-C to USB-C cables

INCLUDED

- 1 board.


RECOMMENDED / REQUIRED [NOT INCLUDED]

- Phillips screwdriver
- Kapton tape
- Soldering iron
- Tin
- Flux
- Desoldering pump
- Desoldering mesh
- Isopropyl alcohol


BOARD DETAILS

This tiny board has eight pads in about 1cm² surface, which means it requires high soldering skills. The following explains what each pad is for.

Nintendo 2DS version (This version has been retired since the new one can be used for both 2DS models):



Nintendo New 2DS XL version:



Starting from the left to the right:

- | | |
|---------|--|
| 1. GND: | The ground pad. |
| 2. GND: | The ground pad. |
| 3. VCC: | The 5V line from the USB-C. |
| 4. GND: | The ground pad. |
| 5. GND: | The ground pad. (Only for Nintendo 2DS) |
| 6. GND: | The ground pad. (Only for Nintendo 2DS) |
| 7. GND: | The ground pad. (Only for Nintendo New 2DS XL) |

INSTALLATION STEPS

Please, carefully read the following steps for a successful installation.

The guide explains how to install the product on a 2DS. If you are installing it in a New 2DS XL, please refer to the following guide to open your device: [ifixit.com](https://www.ifixit.com)

PRE INSTALLATION STEPS

Before the installation, your Nintendo 2DS may need some extra steps to have it ready for the kit.

1. DISASSEMBLY THE NINTENDO 2DS

Nintendo 2DS use the **phillips screws** to close the shell. First remove the two screws which hold the 2DS plastic back cover.




Remove all the accessories such as the battery, stylus, SD card and game card.




Then the ten screws which hold the back shell.




Open the back shell carefully because it is connected to the mainboard with one flex cable. To remove it, lift the plastic retainer and pull back the cable.




Remove all these plastic components:




There are multiple cables connected to the mainboard. All of them need to be disconnected: Lift up on the plastic retainer, grip the cable, and pull back to disconnect it.



Then, remove the last fourteen screws (Be careful with the two lower screws, they are shorter than the rest)



Finally, the mainboard is completely disconnected, and it can be retired aside:



INSTALLATION STEPS

1. PROTECT THE NEAREST COMPONENTS


Use Kapton tape to protect and avoid any damage to the electronic components that are next to the connector.

2. REMOVE UNNECESSARY COMPONENTS

This kit only requires removing the power connector. However, it has many legs, and it may be hard to remove.


If you have an air solder station, you can remove it easily, but protect perfect the nearest places with Kapton tape or something may be burn.

Otherwise, the recommendation is using a **desoldering pump** which will help to remove the tin from each hole/pad.




3. *CLEAN THE BOARD*

After the component is removed, it may be dirty, clean both sides.




4. INSTALLATION OF THE USB-C BOARD



First, the bottom pads of the board need to be pre-soldered with a small amount of tin.




These pads will align with the large holes on the original connector. It is crucial that these two pads are soldered securely as they serve as the main points of support for the board.




Align the board properly and solder the first pad on the bottom side. Then, double-check that the boards are still well aligned and solder the other one.




The board should be completely flat against the Nintendo 3DS mainboard, without any gaps in the middle.



If everything appears to be correct, proceed to solder the remaining four pads.



Optionally, the front side can be painted with a permanent black marker.




Before reassembling everything, you can connect the USB-C cable to the connector and observe if the orange light turns on for a few seconds and then turns off. This confirms that the installation is perfect.



5. CUTTING THE PLASTIC SHELL

The original connector hole in the shell is not enough big for the new USB-C connector, so it needs to be enlarged.



6. FINISHING THE INSTALLATION

Now, you can put the mainboard back to the shell, and put the screws and cables as before. Enjoy it!

