

## CLOCK SPEED (BUS SPEED)

\* NEED ACURATE CONTROL OF TIME

↳ ACTIVATE EXTERNAL CRYSTAL

↳ USE PLL TO SET DESIRED  
BUS SPEED.

①  
↙

USE LIBRARY  
FUNCTION()

②  
↘

ACCESS THE CLOCK  
REGISTERS  
DIRECTLY