


Paper Wristband for Micro:bit



STOP – First Read This

Before Print

1. Use **A4 Paper only**.
2. Please print using Visio or Adobe Acrobat
2. Please use **actual size** option when printing.
3. Your printer may not print in the margin section. It is ok.

After Print

1. Measure the dimension of Microbit rectangle. It should be 50mm x 40mm.
2. If dimensions do not match, you have to reprint with manual scaling while printing.
3. Variation of one or two mm is fine.

Steps (Adult supervision is required)

1. Fold along line A, just to create a crease, **and then unfold**.
2. Reverse fold along line B & C and maintain the fold.
3. Cut out the shaded portion of the microbit rectangle with the help of a cutter and scissors. Please cut through both layer of the paper.
4. Fold along the line A.
5. Fold along the lines D and E.
6. Cut out the shaded portion of band with the help of a cutter and scissors. Please cut through all four layer of the paper.
7. Use masking or paper tape to hold the paper strips (Blue arrows) together.