


Adapter to connect USB peripherals or USB hubs (needs to be plugged into the jack labeled USB)



The jack labeled *PWR* is where you apply power, e.g. from a wall-plug, when the USB jack is connected to a device.


Adapter from mini-HDMI to the more common regular-sized HDMI (to connect to displays and TVs)



Adapter to access the microSD card from your laptop



WiFi network interface in the form of a USB device



Light indicating the Pi is doing something



Pin headers to attach custom electronics to the Pi via cables or a breadboard (can be soldered onto the board)



microSD card containing all of the Pi's program and configuration