

GMMK Pro Cheatsheet

Feb 4, 2022

Shortcuts

Key Combo	Function
Capslock	Hold = numpad; Double tap = numpad toggle
Left Shift	Double press = Capslock
Shift + Backspace	Insert
Invader	Home
Fn + PGUP	Home
Fn + PGDN	End
Fn + Winkey	Windows key locked out (for gaming)
Fn + N	Numlock (system)
Fn + I	Scroll Lock
Fn + U	Print Screen
Fn + P	Pause
Fn + Space	Backspace
Fn + \	Bootloader mode

RGB Functionality

Fn + , or .	RGB lights timeout up/down
Fn + Z	RGB night mode
Fn + A or D	RGB hue up/down
Fn + Q or E	RGB saturation up/down
Fn + W or S	RGB value (brightness) up/down
Fn + Up or Down	RGB effect next/previous
Fn + Left or Right	RGB animation slower/faster
Fn + Home	RGB temporary off

Function Key Row

Key Combo	Function
Fn + F1	My Computer
Fn + F2	Open new browser tab
Fn + F3	Calculator
Fn + F4	My Music
Fn + F5	Media Previous track
Fn + F6	Media Next track
Fn + F7	Media Play
Fn + F8	Media Stop
Fn + F9	Volume Down
Fn + F10	Volume Up
Fn + F11	Print Screen
Fn + F12	Scroll Lock
Fn + Invader	Pause

Rotary Encoder

LShift + Encoder	Cycle layers
RShift + Encoder	PgUp/PgDn
LCtrl + Encoder	Navigate prev/next word
RCtrl + Encoder	RGB hue up/down
LAlt-Encoder	Media prev/next track