







tie digital GND to chassis/earth GND through mounting holes/screws



Since the input only goes slightly negative ($\sim -0.5V$) V_+ may need to be increased by increasing R_5



Should replace the output cap with one rated to $\sim 26V$ in case of failure mode where output can accidentally reach the input voltage Sanyo MV-GX 150μF @ 35V (PN ??)



Sheet: /
File: 5v_psu_oscillator.sch

Title:

Size: A4
KiCad E.D.A. kicad 4.0.6

Date:

Rev:
Id: 1/1