





Designed By GREGORY BAGHDIKIAN	Sheet Name HV_power_supply.SchDoc	PCBAREV	Project	Sheet Number * of *
-----------------------------------	--------------------------------------	---------	---------	------------------------




DesignedBy GREGORY BAGHDIKIAN	Sheet Name level_shift.SchDoc	PCBA REV	Project	Sheet Number * of *
----------------------------------	----------------------------------	----------	---------	------------------------





ADD VOLTAGE DIVIDERS FOR VUS MONITORING







DesignedBy GREGORY BAGHDIKIAN	Sheet Name nixie_tube.SchDoc	PCBA REV	Project	Sheet Number * of *
----------------------------------	---------------------------------	----------	---------	------------------------









VPD CAN BE FROM 5V TO 20V. NEED ZENER CLAMP

