

115VAC 1 ϕ

H

N

G

CB1
20A
1P

G

C1

T1

C1

T2

PUMP
1/2HP
115V 1 ϕ

M

SPRING RETURN
FROM MANUAL

M

FU1
2A/5X20

FS2
START

FS1
STOP

FS3
HIGH LEVEL

FS4
HIGH LEVEL

PS

C

C

PUMP CONTACTOR

R

DOSE TANK
HIGH LEVEL ALARM

BUZZ

R

TREATMENT PLANT
HIGH LEVEL/
LOSS OF PRESSURE
ALARM

BUZZ

FU2
5A/5X20

9

COMPRESSOR

10

IF SYSTEM SUPPLY AIR IS REQUIRED