



120/230V 3WIRE  
SOURCE



CLOCK - PINS OUT= TIME THAT COMPRESSOR WILL BE ON  
PINS IN= TIME THAT COMPRESSOR WILL BE OFF  
ON CLOCK MAKE SURE THAT THE MANUAL-AUTO-OFF LEVER  
IS IN THE CENTER POSITION (AUTO).

 DENOTES PANEL TERMINAL  
-- -- DENOTES FIELD WIRING

OL TRIP  
HIGH LEVEL ALARM

DWG. SCHEM

SCHEMATIC DIAGRAM  
CP1917