

LOR	Seq.	Line of Route Description	ELR	Route	Last Updated
LN101	020	Kings Cross to Shaftholme Jn	ECM1	London North Eastern	01/12/07
Location		Mileage M Ch	Running lines & speed restrictions		Signalling & Remarks
Highdyke		101 46			<div>TCB RA9</div> <div>Doncaster SB (D) AC:York ECR</div> <div>NRN 023</div> <p>TOWS Saltersford DM, UF, US, 103 40 to 104 40.</p> <p>TOWS D&UM 105 20 and 106 40.</p> <p>PP is authorised on the Down/Up Slow Platform for Class 1,2 and 5 trains.</p> <p>PP - Permissive Working - full use for class 1, 2, 3 (ECS), 5, 9 & 0 trains in Platform 3.</p> <p>DUS = Down/Up Slow DUG = Down/Up Goods</p> <p>Class 373/2 trains must not exceed 110 mph on the Down Main/Fast line between Grantham 105 77 and Shaftholme Jn 160 00 (No lineside signs are provided for this speed restriction.)</p>
		104 77 *			
Grantham South Jn		105 01			
		105 10 *			
		105 27 *			
GRANTHAM		105 38			
		105 42 *			
		105 52 *			
		105 77 *			
Nottingham Branch Jn		106 08			
Grantham North Jn		106 34			