

Tool change starts.



Solenoid valve SL09 (spindle taper cleaning) is energized and air is supplied to spindle taper.

DO: SL09 0→1



Tool being changed.



Machine controller confirms completion of tool clamping.



Solenoid valve SL09 (spindle taper cleaning) is de-energized and air supply stops.



Tool change operation completed.