

STRAIGHT CARGO SYSTEM™ – MODEL IPSCS0800

APPLICATION GUIDELINES

- ✓ Do not overload or exceed an automobile, hitch, or cargo carrier manufacturers' weight ratings.
- ✓ Do not install adjacent to any fuel or battery storage.
- ✓ Ensure that the cargo is properly secured.
- ✓ Follow all Federal, State, and Local laws when moving cargo.

Your **Straight Cargo System™** contains the items listed to the right.

Straight Cargo System™ IPSCS0800 is designed to fit cargo carriers with sides / rails that are 4", 5" or 6" high with cargo capacities up to 500 lbs.

- The minimum distance for this installation is 8" between the front rail of the cargo carrier and the rear panel of your vehicle. This will prevent damage to the rear panel of your vehicle.
- For best performance install the Straight Cargo System 20" or greater from the center of your vehicle / hitch.

