



VICTORIA FLYING CLUB

Contact Information

- Stephan Heinemann
- SMS: +1 (250) 891-5446
- Email: stephan.heinemann@hotmail.com
- Bookings, Questions



VICTORIA FLYING CLUB

Aerodrome Traffic Circuit

- Review Slow Flight and Take-Off
- Definition and Motivation
- **Aerodrome Traffic Circuit**
- Summary and Questions
- Pre-Flight Briefing



Review Slow Flight and Take-Off

- Mentally perform a recovery from slow flight and state all observations and required actions.
- What actions have to be completed before initiating a take-off?
- Describe the take-off phases *line-up*, *run* and *initial climb*.
- What are the criteria for a normal take-off?
- Mentally perform a normal take-off and state all observations and actions.
- What causes wake-turbulence and how does it affect your take-off?



Definition and Motivation



- **Standardized** *rectangular* traffic circuit at aerodromes
- **Ordered** and **organized** flow of traffic to avoid conflicts
- Safety and **traffic separation**, **stabilized approaches**
- Types: **controlled** and **uncontrolled** aerodrome circuit
- *Applications*: portion of a circuit is flown in every single flight



VICTORIA FLYING CLUB

Circuit Layout



- Legs: **Take-Off, Crosswind, Downwind, Base, Final**
- Sides: **Upwind** and **Downwind**
- Standard **left-hand** aerodrome circuit with **1000' AAE** circuit height
- Standard crosswind and base legs transition between **500'** and **1000' AAE**
- Consult *Canadian Flight Supplement* for **specific layout** and **procedures**
- Modifications due to **obstacles, noise abatement** and **points of interest**




Circuit Procedures

- **Climb** to **500' AAE** or as assigned on **upwind** leg
- Transition to **Vy** and perform **cockpit checks** (flaps up)
- **Climb** to **1000' AAE** or as assigned on **crosswind** leg
- Perform **cockpit checks** on **downwind** (switches)
- Turn **base leg** at **45°** or as assigned past threshold
- Configure for landing on **downwind** and **final** legs
- Establish **stabilized approach** on final leg
- Maintain *speed and spot* with stable descent rate
- **Go around** if necessary
- Maintain **lookout** and separation: situational awareness



Circuit Radio Procedures and SOPs




- Report **entry** leg
- Report **downwind** leg (standard left or *right*) and **intentions**
- Perform **downwind leg** midfield **checks**
- Report **final leg** – check final items
- Assure **clearances** for **landings** and **deviations** or **exercises** if required in the environment



VICTORIA FLYING CLUB

Controlled Airports Procedures




- Concrete **procedures** are described in the *CFS*
- **Instructions** are to be followed on **towered** airports
- **Advisories** help decision making on **non-towered** airports
- Maintain *constant* **lookout**, **separation** and **order**



VICTORIA FLYING CLUB

Towered Airports (CYYJ)





VICTORIA FLYING CLUB

Towered Airports (CYYJ)

PRO

PPR for non-transponder ops within Victoria Twr class "C" airspace 250-655-2866. VFR dep acft ctc clnc del unless closed by ATIS. Rgt hand circuits Rwy 09, 21 & 31 (CAR 602.96). Ngt ops Rwy 03/21 not auth exc for tkof on Rwy 03. Rwy 03/21 restricted to max 65,000 lbs for tkof and ldg. No weight restriction for taxiing acft Rwy 03/21 south of Rwy 13.

VFR ARR/DEP ROUTES

ARRIVALS:

Beaver Point, Brentwood, Cordova, Cowichan, D'arcy Island, Shawnigan Lake, Stuart Island

ALL ROUTES - Obtain ATIS message

Contact outer twr 119.1

Squawk assigned transponder code

Fly assigned routing

Maintain 2000' until cleared lower or turning final

Contact 119.7 at arrival point for landing instructions

NOTE: If unable contact on 119.7 at arrival point, proceed to final approach and maintain 2000'

DEPARTURES:

Beaver Point, Brentwood, Cordova, Cowichan, D'arcy Island, Moresby Island, Shawnigan Lake, Stuart Island

ALL ROUTES - Fly direct to assigned departure point



Maintain 1500' until cleared higher

Contact 119.1 leaving 1000'



VICTORIA FLYING CLUB

Non-Towered Airports / MF (CYCD)





Non-Towered Airports / MF (CYCD)

PRO

AIRPORT RESTRICTION: Pursuant to CAR 602.96 (3)(d) aprt use rstd acft with a wingspan of less than 118'

Circuit alt 1200 ASL. Avoid flt over built-up areas below 1000 ASL.

Rwy 34:Rgt hand circuits (CAR 602.96). Maintain 1200 ASL til over Ladysmith Harbour. See VTPC.

Rwy 16:Climb to safe alt. Left turn hdg 142° til over Ladysmith Harbour. Climb over Harbour to 1000 ASL BPOC. See VTPC.

Gliders:Circuits to W of aprt.

Procedures for crossing the southern Strait of Georgia within Tml Class C airspace refer to Vancouver Intl, VTPC for Crossing the Southern Strait of Georgia.

ATS REQUIREMENTS:

All VFR acft arriving, departing or transiting the Vancouver or Victoria Tower Class C or D airspace require a transponder code.

- All acft departing Vancouver or Victoria Intl (including Water Aerodrome) call Kamloops FIC at 866-992-7433 (866-WXBRIEF) or 866-541-4101 for code assignment at least 30 min prior to flight or file a VFR Flight Plan/Flight Itinerary.

- All acft arriving Vancouver, Victoria Intl (including Water Aerodrome) or transiting Vancouver or Victoria Control Zones obtain a code from one of the following ATS units: Vancouver Harbour, Nanaimo, Victoria Harbour, Boundary Bay, Langley, Abbotsford or Pitt Meadows, or call Kamloops FIC at 866-992-7433 (866-WXBRIEF) or 866-541-4101.

- All acft arriving Victoria Intl from a non NAV CANADA site call Kamloops FIC at 866-992-7433 (866-WXBRIEF) or 866-541-4101 for code assignment at least 30 minutes prior to flight or file a VFR Flight Plan/ Flight Itinerary.



VICTORIA FLYING CLUB


Uncontrolled Aerodromes



- Located in **uncontrolled airspace (G)**
- Airspace does *not* require radio contact, clearances or special equipment



Uncontrolled Aerodromes Procedures




- Concrete **procedures** are described in the CFS
- Advise other aircraft of your **position** and **intentions**
- Be aware of and lookout for *potential* **NORDO** traffic
- Maintain *constant* **lookout**, **separation** and **order**



VICTORIA FLYING CLUB

Uncontrolled Aerodromes / ATF (CAM3)

| DUNCAN BC | | CAM3 |
|-----------|---|--|
| REF | N48 45 30 W123 43 00 Adj SSW 17°E (2013) UTC-8(7) Elev 300' VTA A5004 |  |
| OPR | Duncan Flying Club 250-216-8001 Reg | |
| PF | B-1 C-2,3,4,5,6 | |
| FLT PLN | NOTAM FILE CYCD | |
| FIC | Kamloops 866-WXBRIEF (Toll free within Canada) or 866-541-4101 (Toll free within Canada & USA) | |
| SERVICES | S 4,5 | |
| RWY DATA | Rwy 13/31 1520x30 asphalt. Rwy 31 up 0.5%. Thld Rwy 13 displ 70'. RCR Opr | |
| LIGHTING | 13-(TE LO), 31-(TE LO) | |
| COMM | ATF tfc 122.8 2NM 3300 ASL | |
| PRO | Rgt hand circuits Rwy 13 (CAR 602.96). NOISE Noise Abatement Procedures: dep Rwy 31, climb rwy hdg, then climb hdg 291° when safe, til clear of subdivision. Avoid noise sensitive area to the E. | |
| CAUTION | Ravines at both ends; gravel pit & 4' windrow W side rwy. Downdrafts, crosswinds & windshear may be encountered. Trees on apch to Rwy 31. <u>Strongly</u> recommended that only pilots familiar with apt & lcl terrain should use this apt dur hrs of darkness. | |



VICTORIA FLYING CLUB



Crossing Control Zones



- Crossing requirements depend on airspace structure
- Radio contact, transponder, clearance, routing
- Refer to *Terminal Chart* and CFS procedures



Special VFR



- Allows to enter a control zone in IMC under VFR
- Special VFR has to be requested **by the pilot**
- Special VFR can be **denied** due to IFR traffic



VICTORIA FLYING CLUB

Summary / Quiz

- What are the two main types of circuits and how do they differ?
- Describe the standard circuit with respect to legs, sides, directions and heights.
- Where do you find what particular circuit and procedure applies to an aerodrome?
- Assume you want to join the Nanaimo traffic circuit approaching from Victoria. The ATIS informs you that the weather is VFR and the active runway is 34. Mentally perform the procedure and state all observations and required actions.



VFR Minima

Figure 2.7 – VFR Weather Minima*

| AIRSPACE | | FLIGHT VISIBILITY | DISTANCE FROM CLOUD | DISTANCE AGL |
|---------------------------|--------------------------------------|--|--|----------------------|
| Control Zones | | not less than 3 miles** | horizontally: 1 mile vertically: 500 feet | vertically: 500 feet |
| Other Controlled Airspace | | not less than 3 miles | horizontally: 1 mile vertically: 500 feet | — |
| Uncontrolled Airspace | 1 000 feet AGL or above | not less than 1 mile (day) 3 miles (night) | horizontally: 2 000 feet vertically: 500 feet | — |
| | below 1 000 feet AGL – fixed-wing | not less than 2 miles (day) 3 miles (night) (see Note 1) | clear of cloud | — |
| | below 1 000 feet AGL – helicopter | not less than 1 mile (day) 3 miles (night) (see Note 2) | clear of cloud | — |



VICTORIA FLYING CLUB

Pre-Flight Briefing

- Exercise
- Training Area
- Departure and Arrival Procedures
- Weather Briefing / NOTAMs
- Aircraft and Documents
- Time and Fuel Requirements
- Safety Considerations and Responsibilities



VICTORIA FLYING CLUB

Pre-Flight Briefing

- Exercise
- Training Area
- Departure and Arrival Procedures
- Weather Briefing / NOTAMs
- Aircraft and Documents
- Time and Fuel Requirements
- Safety Considerations and Responsibilities



VICTORIA FLYING CLUB

The Circuit (Ex. 17, LP. 3-10, 20)

- Objective
- Review
- Motivation
- Howto
- Summary / Questions
- Preflight Briefing



VICTORIA FLYING CLUB

Terminal and Transition Airspace