

## **HAL and XML File explanation for 2 Motors in CSP Mode**

Note: The CSP2Motor hal and xml file need not be changed.

Learn more about HAL [here](#) and learn more about adding slaves into xml file [here](#).

After adding required number of slaves in the xml file, go to HAL file.

In line 3 of HAL file, make the count equal to the number of slaves you have (in this case 2).

The use the addf command to add limit3 for you slave. There should be limit3 for every slave added.