

Safety Gear

The safety gear on the boat includes life jackets, EPIRB's , self inflating life raft.



The lifejackets and bosun's chair are stored under the seat cushion in the saloon.



Two of the jackets are fitted with automatic inflation and automatic activation AIS devices. They also have a light and whistle and safety tether with hooks to clip on to strong points or safety life lines on the deck.



Safety Gear

The safety gear on the boat includes life jackets, EPIRB's , self inflating life raft.



The life raft is located on the aft deck below the seat next to the dinghy. It is mounted on a tube frame fixed to the deck and tied to the frame with a quick release cord with a snap shackle. Pull the snap shackle and push the liferaft horizontally and it will fall overboard into the water and the rip cord / lanyard also attached to the frame will self inflate the dinghy. Once in the dinghy the lanyard is cut and the dinghy will float away from the boat.

The liferaft is fitted with an EPIRB and flares and emergency provisions including water.



Floating waterproof grab container taken with you into the liferaft when abandoning ship. On ocean passages store passports, wallets and other valuables in this container. We also use it to store the ships emergency flares.



Man overboard floating life ring and floating light. Light automatically comes on in the water.

Safety Gear

The safety gear on the boat includes life jackets, EPIRB's , self inflating life raft, fire extinguishers, etc.



The bosun's chair is used to gain access when you need to work on the mast. Connect the mainsail halyard shackle to the lifting ring on the chair and use the anchor winch capstan to winch you up. Always have another person operating the winch and make sure the mainsail halyard cam lock is locked on the halyard except when lowering you down.



The boat has fire extinguishers in each cabin and in the main saloon. Fire blankets are also located in the galley area.



Man overboard floating life ring and floating light. Light automatically comes on in the water.