


It is essential that the wick tubes and feed tube are silver soldered together.
Tank may be soft soldered though silver solder would be preferred.


Wick tubes, 10mm or 3/8" thin wall brass tube

Filler, 6mm or 1/4" brass tube


Crosses show where burner fits in relation to the axes






Bases for wick tubes, 12mm diameter thin brass sheet



Feed tube, 3/16" or 4mm tube
Cut notch as shown to allow meths into wick tube



Overflow
3mm or 3/32" tube



Retaining clips (2 off), thin brass, bend to shape shown.
Soft solder bottom edge in place on sides of tank
after completing tank

Meths tank
sides and back
thin brass sheet

Wild Rose III
sheet 20
Meths burner

Copyright Dave Watkins 26/3/2012