





Short Chimney for open cab loco, brass
Must be silver soldered in place for gas firing



Tall Chimney for closed cab loco
cap and base as for short chimney




Smokebox door.
Door brass, hinges from 0.5mm brass.
This can be soft soldered to smokebox front for meths firing .
For gas firing it should be hard soldered,
An opening door can make lighting the gas easier.



A domestic pin can be
used as a hinge pin
with short lengths of
2mm diameter tube to
represent the lugs on
the smokebox.


Trim bottom edge of smokebox door

Smokebox front, 1.5mm brass



1.8mm fixing holes for 10BA bolts
to secure to footplate angle

Smokebox wrapper, 0.5mm brass
can be soft soldered to smokebox front for meths firing,
hard solder for gas firing. Add rivet detail if desired.



Wild Rose III
sheet 25
Smokebox

Copyright Dave Watkins 11/6/2012