


Cab back, 0.5mm brass sheet


Top and bottom rails




Add rivet detail if desired
(see general arrangement drawings)

rear side peices (2 off)


doors (2 off)



Cab side, 0.5mm brass sheet
1 off as shewn, 1 off reversed.



Brass beading rom 3mm (1/8") brass boiler band strip



Assemble cab back with soft solder (except handrails)
and fix to length of 5mm angle for securing to footplate.

Handrails from 1.6mm rod, best silver soldered to cab beading
before soft soldering beading in place.

Wild Rose III
sheet 26
Open Cab

Copyright Dave Watkins 11/6/2012