

Congratulations on your purchase of the 4-in-1 Hair Straightener, Curler, Crimper Amazon Iron! This user manual will guide you on how to effectively and safely use this versatile hair styling tool to create different hairstyles. Please read this manual carefully before using the product.

**Product Overview:** The 4-in-1 Hair Straightener, Curler, Crimper Amazon Iron is a multifunctional hair styling tool that combines four different styling functions in one device. With this iron, you can straighten, curl, wave, or crimp your hair, allowing you to achieve a variety of hairstyles with ease. Its compact design and user-friendly features make it suitable for both professional and home use.

**Important Safety Precautions:**

1. Read all instructions before using the Amazon iron and keep them for future reference.
2. This iron is for household use only. Do not use it in a bathroom or near water sources.
3. Unplug the iron when not in use and before cleaning.
4. Do not immerse the iron in water or any other liquids.
5. Do not use the iron if the cord or plug is damaged.
6. Do not use the iron with an extension cord.
7. Keep the iron away from heat sources and flammable materials.
8. Use the iron on dry hair only. Do not use it on wet or damp hair.
9. Do not touch the heated plates with bare skin during or immediately after use, as they may be hot and cause burns.
10. Keep the iron out of reach of children and pets.

**Usage Instructions:**

1. Power On and Temperature Selection:

- Plug the iron into a suitable power outlet.
- Press the power button to turn on the iron.
- The LED indicator will light up, indicating that the iron is powered on.
- Use the temperature control buttons to adjust the desired heat setting. The LED display will show the selected temperature.
- Choose a lower temperature for fine or delicate hair and a higher temperature for thick or coarse hair.
- Allow the iron to heat up to the desired temperature before use.

## 2. Straightening:

- Ensure your hair is clean, dry, and free of tangles or knots.
- Take a small section of hair and place it between the heating plates of the iron.
- Gently clamp the iron on the hair section, close to the roots.
- Slowly glide the iron down the hair shaft, from the roots to the ends, maintaining a steady and even pressure.
- Repeat this process for each hair section until you achieve the desired straightness.

## 3. Curling:

- Select the curling barrel attachment suitable for the desired curl size (large, medium, or small).
- Take a small section of hair and wrap it around the curling barrel, starting from the roots.
- Hold the iron in place for a few seconds, allowing the hair to heat up and set the curl.

- Gently release the hair from the curling barrel to reveal the curled hair.
- Repeat this process for each hair section until you achieve the desired curls.

#### 4. Waving:

- Select the waving plate attachment suitable for the desired wave pattern (deep or subtle waves).
- Take a small section of hair and place it between the waving plates of the iron.
- Gently clamp the iron on the hair section and hold it for a few seconds.
- Release the iron and move it down the hair section, creating a wave-like pattern.
- Repeat this process for each hair section until you achieve the desired waves.

#### Cleaning and Maintenance:

Unplug the iron and allow it to cool down before cleaning.

Use a soft, damp cloth to wipe the plates or attachments to remove any hair product buildup or residue.

Do not immerse the iron or its attachments in water.

Store the iron in its original packaging or a suitable protective case to prevent damage.

Note: Always follow the manufacturer's instructions regarding the proper usage and care of your specific 4-in-1 Hair Straightener, Curler, Crimper Amazon Iron model, as features and instructions may vary slightly between different brands and models.

Enjoy experimenting with different hairstyles using your 4-in-1 Hair Straightener, Curler, Crimper Amazon Iron, and have fun styling your hair!