

Introduction	1
Checklist	1
Activation procedure	1
Next steps	3

Introduction

Iddero Voice Control lets you control compatible Iddero products by voice using Amazon Alexa.

The service must be activated for each Iddero device separately; an activation code is required for each device. To request activation codes, please contact our sales team: sales@iddero.com.

Checklist

Before requesting an activation code, make sure you meet all requirements:

- ☐ I have a compatible Iddero device:
 - ☐ VERSO+IP 2 with firmware version 3.0 or later
 - ☐ VERSO INDOOR with firmware version 3.0 or later
 - ☐ HC3-KNX with firmware version 5.0 or later
 - ☐ HC3L-KNX with firmware version 5.0 or later
 - ☐ Iddero Home Server 3 with firmware version 5.0 or later
- ☐ The device is linked to idderocloud and can be accessed over the Internet
- ☐ I have verified that the “Iddero Voice Control” skill is available in my region and appears when searching for it in the Alexa app


Activation procedure

1. Sign in to your idderocloud account
2. Locate the device you want to activate the service for
3. Click the microphone icon next to the device
4. Click “Check firmware”
5. If everything is correct, a field will appear where you can enter the activation code: enter the code and click “Activate service”


Note: each activation code can only be used once.

Application note


Iddero Voice Control Service Activation



From your idderocloud account, click the microphone icon next to the device you want to activate the service for.



Click “Check firmware” to verify that everything is correct.



Enter the activation code and click “Activate service”.

Next steps

After activating the service, you must configure voice control. This is a very simple process that can be carried out either by the installer or the end user. Please refer to the quick setup guide available at the following link:

https://www.iddero.com/files/VoiceControl_Quick_setup_en.pdf