

INSTALLATION

Installation is in the reverse order of removal (See page BR-12).

HINT:

After the installation, check and adjust parking brake pedal travel (See page BR-9).