


INNER REAR VIEW MIRROR ASSY REPLACEMENT

7011K-01

HINT:

- The installation procedures are the removal procedures in reverse order.
- Use the same procedures for the RH side and LH side.
- The procedures listed below are for the LH side.
- A bolt without a torque specification is shown in the standard bolt chart (see page 03-2).




1. REMOVE MAP LAMP ASSY

- (a) Open the upper console.
- (b) Using a screwdriver, pry out the lens cover.

HINT:

Tape the screwdriver tip before use.




- (c) Using a screwdriver, pry out the 2 caps.

HINT:

Tape the screwdriver tip before use.

- (d) Remove the 4 screws.
- (e) Remove the map lamp and disconnect the connector.



2. REMOVE INNER REAR VIEW MIRROR ASSY

- (a) Remove the 2 screws and mirror.
- (b) Disengage the connector from the body.