

INSPECTION

1. CHECK EVAPORATOR AND HEATER RADIATOR FINS FOR BLOCKAGE

If the fins are clogged, clean them with compressed air.

NOTICE:

Never use water to clean the evaporator.

2. CHECK FITTINGS FOR CRACKS OR SCRATCHES

Repair as necessary.

3. INSPECT WATER VALVE CONTROL SERVOMOTOR CIRCUIT ([See page DI-1836](#))

4. INSPECT AIR OUTLET DAMPER CONTROL SERVOMOTOR CIRCUIT ([See page DI-1839](#))