





























STANDARD BOLT

HOW TO DETERMINE BOLT STRENGTH

031RO-02

Bolt Type				Class
Hexagon Head Bolt		Stud Bolt	Weld Bolt	
Normal Recess Bolt	Deep Recess Bolt			
<div></div> <div> No Mark</div>	<div> No Mark</div>	<div> No Mark</div>	<div></div>	4T
<div></div> <div></div>	<div></div>			5T
<div></div> <div><div> w/ Washer</div></div>	<div><div> w/ Washer</div></div>	<div></div>		6T
<div></div> <div></div>	<div></div> <div></div>			7T
<div></div>	<div></div>	<div></div> <div></div>		8T
<div></div>	<div></div>			9T
<div></div>	<div></div> <div></div>			10T
<div></div>	<div></div> <div></div>			11T