

PROGRESSIVE POWER STEERING SYSTEM

05HZE-01

PRECAUTION

NOTICE:

When the negative (-) battery terminal is disconnected, initialize the following systems after the terminal is reconnected.

System Name	See page
Power Window Control System	01-20
Front Power Seat Control System	01-20
Back Guide Monitor System	01-20