



## REMOVAL

1. REMOVE LOWER CENTER FINISH PANEL
2. REMOVE LOWER CENTER CLUSTER FINISH PANEL
3. REMOVE RADIO ASSEMBLY




### 4. REMOVE MULTI DISPLAY ASSEMBLY

- (a) Using a screwdriver, release the 4 claws and remove the temperature control switches.
- (b) Disconnect the connectors.



- (c) Remove the 4 bolts.



- (d) Release the 4 claws and remove the multi display assembly.