






















STANDARD BOLT

HOW TO DETERMINE BOLT STRENGTH

031Q8-01

Bolt Type				Class
Hexagon Head Bolt		Stud Bolt	Weld Bolt	
Normal Recess Bolt	Deep Recess Bolt			
 No Mark	 No Mark	 No Mark		4T
 No Mark				5T
 w/ Washer	 w/ Washer			6T
 No Mark				7T
		 		8T
				9T
				10T
				11T

B06431