


# LOCATION

FL Block Assy \*3

- D/C CUT Fuse
- ALT H-fuse
- D-J/B H-fuse
- P-J/B H-fuse



Passenger Side J/B \*3


- D DOOR Fuse
- MPX-B1 Fuse

Driving Position Memory Switch \*3

Transponder Key ECU\*1 \*3

Gateway ECU \*3

Theft Deterrent ECU \*3



\*1: w/o Smart Key System

\*2: w/ Smart Key System

\*3: For RHD vehicles, look at the same location on the opposite side of the vehicle.

Driver Side J/B \*3

- IG1 Relay
- MPX-IG Fuse
- D-P/SEAT Fuse
- AM1 Fuse
- D-RR-IG Fuse

Steering Lock ECU\*2 \*3

Driver Door ECU \*3

