


ROUTE CANNOT BE CALCULATED**INSPECTION PROCEDURE****1 CHECK THE MAP DISC**

(a) Check that the map disc is not deformed or cracked.

OK: No deformations or cracks appear on the map disc.**NG****REPLACE THE MAP DISC****OK****2 SET DESTINATION**

(a) Set another destination and check if the system can calculate the route correctly.

OK: Route can be correctly calculated.**OK****NORMAL OPERATION****NG****PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE
(SEE PAGE 05-1771)**