

POWER DOOR LOCK CONTROL SYSTEM

05HYN-01

PRECAUTION

NOTICE:

When disconnecting the negative (-) battery terminal, initialize the following systems after the terminal is reconnected.

System Name	See Page
Power Window Control System	05-1984
Front Power Seat Control System	05-2280
Back Guide Monitor System	05-1913