

INSTALLATION

Installation is to be done in the reverse order of removal (See page BR-57).

HINT:

- After installation, fill the brake reservoir with brake fluid and bleed the brake system (See page BR-4).
- Check for fluid leakage.