


BODY DIMENSION DRAWINGS

ENGINE COMPARTMENT

(Three-Dimensional Distance)

	RHD	LHD
A-a	1,489 (58.62)	—
G-g	848 (33.39)	—
C-K or c-k	157 (6.18)	—
D-A	786 (30.94)	987 (38.86)
D-a	987 (38.86)	786 (30.94)
D-B	416 (16.38)	606 (23.86)
D-b	606 (23.86)	416 (16.38)
D-E	840 (33.07)	947 (37.28)
D-e	947 (37.28)	840 (33.07)
D-F	558 (21.97)	704 (27.72)
D-f	704 (27.72)	558 (21.97)
D-G	878 (34.57)	987 (38.86)
D-g	987 (38.86)	878 (34.57)




HINT: For symbols, capital letters indicate right side of vehicle, small letters indicate left side of vehicle (Seen from rear).

mm (in.)

Symbol	Name	Hole dia.	Symbol	Name	Hole dia.
A, a	Radiator upper support standard hole	10 (0.39)	G, g	Radiator center support installation nut	6 (0.24) nut
B, b	Front spring support hole-inner	13 (0.51)	H, h	Radiator center support installation nut	6 (0.24) nut
C, c	Cowl top side panel standard hole	10 (0.39)	I, i	Radiator support standard hole	10 (0.39)
D	Cowl top panel standard hole	8 (0.31)	J	Hood lock brace installation nut	6 (0.24) nut
E, e	Stabilizer bracket installation nut-front	8 (0.31) nut	K, k	Hood hinge installation nut-rear	8 (0.31) nut
F, f	Front side member standard hole	15 (0.59)	—	—	—

BODY OPENING AREAS (Side View: Front)

(Three-Dimensional Distance)



Vehicle Dimensions Left ↔ Right

E-e	F-f	G-g	H-h	I-i	J-j
1,284 (50.55)	1,530 (60.24)	1,542 (60.71)	1,173 (46.18)	1,293 (50.91)	1,542 (60.71)

HINT: For symbols, capital letters indicate right side of vehicle, small letters indicate left side of vehicle (Seen from rear).


E-f or e-F	E-g or e-G	E-i or e-I	F-i or f-I	F-j or f-J	G-h or g-H	I-j or i-J
1,616 (63.62)	1,666 (65.59)	1,416 (55.75)	1,871 (73.66)	1,777 (69.96)	1,711 (67.36)	1,571 (61.85)

mm (in.)

Symbol	Name	Hole dia.	Symbol	Name	Hole dia.
A, a	Roof panel/Front body pillar adjoining portion	—	G, g	Rocker panel assembly mark	—
B, b	Cowl top panel/Front body pillar adjoining portion	—	H, h	Roof side rail assembly mark	—
C, c	Front door hinge installation nut	10 (0.39) nut	I, i	Center body pillar assembly mark	—
D, d	Front door hinge installation nut	10 (0.39) nut	J, j	Center body pillar assembly mark	—
E, e	Front body pillar assembly mark	—	K, k	Rear door hinge installation hole	13 (0.51)
F, f	Front body pillar assembly mark	—	L, l	Rear door hinge installation hole	13 (0.51)

BODY OPENING AREAS (Side View: Rear)

(Three-Dimensional Distance)



HINT: For symbols, capital letters indicate right side of vehicle, small letters indicate left side of vehicle (Seen from rear).

Vehicle Dimensions Left ↔ Right


M-m	N-n	O-o	P-p	Q-q	R-r
1,309 (51.54)	1,542 (60.71)	1,542 (60.71)	1,160 (45.67)	1,227 (48.31)	1,542 (60.71)

Symbol	Name	Hole dia.	Symbol	Name	Hole dia.
G, g	Rocker panel assembly mark	—	O, o	Rocker panel assembly mark	—
H, h	Roof side rail assembly mark	—	P, p	Roof side rail assembly mark	—
M, m	Center body pillar assembly mark	—	Q, q	Quarter panel assembly mark	—
N, n	Center body pillar assembly mark	—	R, r	Quarter panel assembly mark	—

mm (in.)

BODY OPENING AREAS (Rear View)

(Three-Dimensional Distance)




HINT: For symbols, capital letters indicate right side of vehicle, small letters indicate left side of vehicle (Seen from rear).

Symbol	Name	Hole dia.	Symbol	Name	Hole dia.
A, a	Center body pillar assembly mark	—	E, e	Luggage opening trough/Quarter panel adjoining portion	—
B, b	Roof panel/Quarter panel adjoining portion	—	F, f	Lower back reinforcement/Lower back panel adjoining portion	—
C, c	Upper back panel/Quarter panel adjoining portion	—	G, g	Quarter panel standard hole	10 (0.39)
D, d	Quarter panel/Upper back panel adjoining portion	—	H, h	Rear spring support hole-outer	13 (0.51)

UNDER BODY


(Three-Dimensional Distance)



Symbol	Name	Hole dia.	Symbol	Name	Hole dia.
A, a	Air duct installation nut	6 (0.24) nut	H, h	Front floor reinforcement standard hole	15 (0.59)
B, b	Front crossmember reinforcement standard hole	10 (0.39)	I, i	Propeller shaft installation nut	10 (0.39) nut
C, c	Front side member standard hole	18 (0.71)	J, j	Rear floor side member standard hole	18 (0.71)
D, d	Front frame installation nut	16 (0.63) nut	K, k	Rear suspension member installation nut	14 (0.55) nut
E, e	Front frame installation nut	16 (0.63) nut	L, l	Rear suspension member installation nut	14 (0.55) nut
F, f	Front side member standard hole	18 (0.71)	M, m	Transport hook installation nut	12 (0.47) nut
G, g	Engine rear mounting member installation nut-rear	10 (0.39) nut	—	—	—


mm (in.)

UNDER BODY (Cont'd)






FRONT SUSPENSION CROSSMEMBER

(Three-Dimensional Distance)



(Two-Dimensional Distance)




Symbol	Name	Hole dia.	Symbol	Name	Hole dia.
A, a	Suspension lower arm installation hole-front	23 x 14.5 (0.91 x 0.571)	D, d	Lower arm bracket installation nut	12 (0.47) nut
B, b	Front frame installation hole	22 (0.87)	E, e	Front frame installation hole	24 (0.94)
C, c	Front frame standard hole	15 (0.59)	—	—	—




mm (in.)

REAR SUSPENSION MEMBER

(Three-Dimensional Distance)



(Two-Dimensional Distance)



Symbol	Name	Hole dia.	Symbol	Name	Hole dia.
A, a	Suspension lower arm installation hole-rear	12.2 (0.480)	E, e	Suspension lower arm installation hole-front	12.2 (0.480)
B, b	Rear suspension member standard hole	15 (0.59)	F, f	Rear suspension member standard hole	12 (0.47)
C, c	Rear suspension member standard hole	15 (0.59)	G, g	Suspension upper arm installation hole-rear	12.2 (0.480)
D, d	Suspension upper arm installation hole-front	12.2 (0.480)	H, h	Stabilizer installation nut	8 (0.31) nut

MEMO