













FUEL


PREPARATION

SST


023F4-01

	09023-12700	Union Nut Wrench 17mm	FUEL SYSTEM
	09023-38400	Union Nut Wrench 14mm	FUEL SYSTEM
	09268-41047	Injection Measuring Tool Set	FUEL SYSTEM
	(09268-41110)	Adaptor	FUEL SYSTEM
	(09268-41300)	Clamp	FUEL SYSTEM
	(09268-52011)	Injection Measuring Attachment	FUEL SYSTEM
	(95336-08070)	Hose	FUEL SYSTEM
	09268-45014	EFI Fuel Pressure Gauge	FUEL SYSTEM
	(09268-41190)	Adapter	FUEL SYSTEM
	(90405-06167)	Union	FUEL SYSTEM
	09612-24014	Steering Gear Housing Overhaul Tool Set	FUEL SYSTEM
	(09617-24011)	Steering Rack Wrench	FUEL SYSTEM

PREPARATION - FUEL

	09842-30070 Wire "F" EFI Inspection	FUEL SYSTEM
---	-------------------------------------	-------------

Recomended Tools

	09082-00040 TOYOTA Electrical Tester	FUEL SYSTEM
---	--------------------------------------	-------------

Equipment

Battery	
Clip remover	
Radiator cap tester	
Stop watch	
Torque wrench	