

PROBLEM SYMPTOMS TABLE

Use the table below to help find the cause of the problem. The numbers indicate the likelihood of the possible cause of the problem. Check each part in order. Replace parts as necessary.

Symptom	Suspected Area	See page
Bottoming	1. Vehicle (Overloaded) 2. Pneumatic shock absorber (Worn) 3. Spring (Weak) 4. Shock absorber (Worn)	- 27-10 27-15 27-15
Sways/pitches	1. Tire (Worn or improperly inflated) 2. Stabilizer bar (Bent or broken) 3. Shock absorber (Worn)	28-1 27-29 27-15
Rear wheel shimmy	1. Tire (Worn or improperly inflated) 2. Wheel (Out of balance) 3. Pneumatic shock absorber (Worn) 4. Shock absorber (Worn) 5. Wheel alignment (Incorrect) 6. Hub bearing (Worn)	28-1 28-1 27-10 27-15 26-8 27-8 30-31
Abnormal tire wear	1. Tire (Worn or improperly inflated) 2. Wheel alignment (Incorrect) 3. Pneumatic shock absorber (Worn) 4. Shock absorber (Worn) 5. Suspension parts (Worn)	28-1 26-8 27-8 27-10 27-15 -