

PROBLEM SYMPTOMS TABLE

Check the circuits for each problem symptom in the order given in the table below, and proceed to the relevant troubleshooting page.

Symptom	Suspected Area	See page
When shift lever is in R position, rear view monitor image is not displayed (Screen is not black).	1. Power source circuit 2. Neutral start switch 3. Television camera ECU	05-1964 05-563 67-15
When shift lever is in R position, rear view monitor image is not displayed (Screen is black).	1. Display signal circuit (Television camera assy – Television camera ECU) 2. Television camera assy 3. Television camera ECU	05-1970 67-14 67-15
When shift lever is not in R position, rear view monitor image is displayed.	1. Neutral start switch 2. Television camera ECU	05-563 67-15
Problem with the rear view monitor image (color, disorder of picture).	1. Display signal circuit (Television camera assy – Television camera ECU) 2. Display signal circuit (Television camera ECU – Multi-display) 3. Television camera assy 4. Television camera ECU 5. Multi-display	05-1970 05-1968 67-14 67-15 67-8