

PARKING BRAKE COMPONENTS

BR0CU-06

Left Wheel:

Right Wheel :

Pad Wear
Indicator
Assembly

Bleeder
Plug Cap

Clamp

◆ Clip

Brake Caliper

◆ 78 (800, 58)

Pin

76 (775, 56)

Upper Shoe

Shoe Hold-down Spring

Cap

Adjuster

Adjuster

Anchor Block

Tension Spring

Parking Brake Shoe
Lever

Return Spring

Lower Shoe

Shoe Hold-down Spring

Cap

Disc

Hole Plug

N·m (kgf·cm, ft·lbf) : Specified torque

◆ Non-reusable part

↔ High temperature grease

F13216