



!p(a1o6s)



make sure
this matches
the paper you
are using



make sure this matches these

make sure this matches these





wanna
actually
rtfm?

gr|aid|ent

r
t
f
m

table of

contents



feeding dials
are located here


- Ⓢ Normal Paper 20lb-40lb
- ◯ Slick Paper
- ◯ Heavy paper 110lb
- Card/envelope

loose suggestions


Normal	9:00	12:00
Slick	12:00	2:00
Heavy	3:00	1:00
Card	6:00	3:00

turn up
if feeding
multiple sheets

turn down
if the feeder
is skipping



angle dial



pressure dial