


IBeam

Installation Guide



Important Installation Considerations


Please read all of the instructions before installation.

Not installing the Arctic roller mechanism correctly may cause damage - refer to Arctic installation instructions.


These instructions include the following:

Contents.....	Page 3
Window Installation Instructions.....	Page 4-5
Sliding Door Installation Instructions.....	Page 6-7
Pivot Door Installation Instructions.....	Page 8-11


Components




CI-0523
IBeam Top &
Bottom Door
Rail




CI-0524
IBeam Door
Rail



CI-0555
IBeam Sliding
Door Top Rail




CI-0530
IBeam Window
Frame




CI-0550
IBeam Window
Sill



CI-0551
IBeam Sill
Bead



CI-0578
IBeam 2 Way
Corner Post



CI-0560
IBeam Pocket
Filler



CI-0562
IBeam Door
Stop




CI-0540
IBeam 3 Way
Adaptor



CI-817506
IBeam Spigot



CI-0580
IBeam Cross
Beam




CI-0553
IBeam Sliding
Track




CI-0541
IBeam Pelmet




CI-0526
IBeam Sliding
Track Mounting
Bracket



CI-817502
IBeam Inner
Bracket



CI-817503
IBeam Right
Angle Bracket



CI-817504
IBeam Plastic
Frame Cap




CI-817505
IBeam Plastic
Sliding Door
Cap



CI-817507
Criterion Pivot


IBeam Window[®] Installation Instructions

IBeam Window[®] Installation Instructions




Step 1.

Slide CI-817502 IBeam Inner Bracket into the glazing pocket of CI-0550 IBeam Window Sill.




Step 2.

Fix the CI-817502 IBeam Inner Bracket using two 10g screws through the frame into the floor.



Step 3.

Slide CI-0530 IBeam Window Frame onto CI-817502 IBeam Inner Bracket.





Step 4.

Fix CI-817502 IBeam Inner Bracket to CI-0530 IBeam Window Frame. Double side tape CI-817504 IBeam Plastic Frame Cap to all corners of windows.

*Repeat the four steps for all window corner details.

IBeam Pivot Door® Installation Instructions

IBeam Pivot Door® Installation Instructions




Step 1.

Connect CI-0562 Door Stop to CI-0530 IBeam Window Frame at the door opening created from steps 1-4.

Step 2.

Fix MDF packers inside both CI-0523 IBeam Top & Bottom Door Rail to allow fixing for the CI-817507 Criterion Pivot.




Step 3.

Position the Pivot Door in position and Fix. See pivot instructions for fixing.


IBeam Sliding Door® Installation Instructions

IBeam Sliding Door® Installation Instructions




Step 1.

Position CI-0526 IBeam Sliding Track Mounting Bracket within CI-0530 IBeam Window Frame.




Step 2.

Drill a large clearance hole into CI-0553 IBeam Sliding Track. Fit CI-0553 IBeam Sliding Track onto CI-0526 IBeam Sliding Track Mounting Bracket. Fix through pilot holes into CI-0530 IBeam Window Frame every 300mm.



Step 3.


Load the track with Arctic roller mechanism. Please refer to Arctic Instructions.



Step 4.


Position the IBeam End Cap to the ends of CI-0553 IBeam Sliding Track.

IBeam Sliding Door® Installation Instructions




Step 5.

Clip on CI-0560 Pocket Filler on the external sides of the vertical CI-0524 IBeam Door Rails.




Step 7.

Double side tape the CI-817505 IBeam Plastic Sliding Door Cap to the door as shown in the image above.



Step 6.


Fit a timber packer down into the CI-0524 IBeam Door Rails and mount the Arctic Roller Sleeve to the top of the door.



Step 8.

Hang the door into position.

IBeam Sliding Door® Installation Instructions



Step 9.

Fit CI-0541 IBeam Pelmet to
CI-0553 IBeam Sliding Track.

Important Considerations

This product is covered by a 10 year replacement product warranty and spare parts.

This warranty will apply only under all of the following conditions:

The item has been installed by a licensed and registered builder/installer.

The installation of the product is in accordance with the instructions provided.

Failure is due to a fault in the manufacture of the product.

Proof of purchase (including the date of purchase) is provided.

This warranty does not include faults caused by: Unsuitable or improper use.

Incorrect installation or installation not in accordance with the instructions provided.

Installation or part installation by the purchaser or any person other than a licensed and registered builder/installer.

Normal wear and tear.

For more information visit:

www.criterionindustries.com.au/ibeam

VIC

15 Corporate Place
Broadmeadows, VIC, 3047
T: 03 9355 0700

sales@criterionindustries.com.au

NSW

95 Victoria Street
Smithfield, NSW, 2164
T: 02 9355 0700

sales.nsw@criterionindustries.com.au

WA

58 Tacoma Circuit
Canning Vale WA 6155
T: 08 9355 0700

sales.wa@criterionindustries.com.au

Technical Specifications:

- Arctic Roller Set

- Cycle Tested

Ensure the item has been installed by a
licensed and registered builder/installer