






\*POSITION OF IMU CENTER



ACTUAL SIZE

\*NOTE: FOR BEST PERFORMANCE TOP/BOTTOM PADS AND/OR CENTER PADS NEED TO BE SOLDERED TO INCREASE SURFACE CONTACT



RECOMMENDED  
FOOTPRINT

INERTIAL SENSE  
72 N 720 E  
Salem, UT 84653



**INERTIAL SENSE**  
autonomous navigation solutions

TITLE:

**IS-IMX-5.x.x**

SIZE

**A**

DWG NO

**IS-IMX-5.0-PINOUT**

REV


**A**

SCALE 3:1


DRAWN: ANDREW PRIDDIS

SHEETS 1 OF 2

ALL DIMENSIONS IN MM  
LINEAR DIMENSIONS  $\pm 0.01$  MM



TOP VIEW

|   |  |   |  |   |  |
|---|--|---|--|---|--|
| INERTIAL SENSE<br>72 N 720 E<br>Salem, UT 84653 |  |  |  | INERTIAL SENSE<br>autonomous navigation solutions |  |
| TITLE:<br><br>IS-IMX-5.x                        |  |   |  |   |  |
| SIZE<br><br>A                                   |  | DWG NO<br><br>IS-IMX-5.x-PINOUT   |  | REV<br><br>A                                      |  |
| SCALE 8:1                                       |  | DRAWN: ANDREW PRIDDIS   |  | SHEETS 2 OF 2                                     |  |