


Step 1:

Step 1:

Insert the *Camera Mount Component V2 - PCB Holder.stl* into the *Camera Mount Component V2 - Tilt Holder.stl*



Step 2: Affix the tilt servo horn into the *Camera Mount Component V2 - PCB Holder.stl* with glue.

