



- Notes:
- 1. Blue lines represent part geometry. Do not silk screen.
  - 2. Orient part so that counterbore side of holes is on top (silk screen) side