

---

```

clc;
clear;

V_r = 400e3; % Receiving voltage
P_r = 400e6; % Receiving Side Power
pf = 0.9;    % Power factor
length = 20; % Transmission line length
R_per_km = 0.01; % Resistance Per KM
X_per_km = 0.1; % Reactance Per KM

Z = (R_per_km + 1j*X_per_km) * length; % Formula for total impedance
V_r_phase = V_r / sqrt(3); % Receiving Voltage Per Phase
I_r = (P_r / (sqrt(3)*V_r*pf)); % Receiving End current Per Phase
phi = acos(pf);
I_r_phasor = I_r * exp(-1j*phi); % Phasor Current angle

V_s_phase = V_r_phase + Z * I_r_phasor; % Receiving End Voltage
V_s = (V_s_phase) * sqrt(3);
P_s = 3 * real(V_s_phase * conj(I_r_phasor)); % Receiving end Power
efficiency = (P_r / P_s) * 100; % System Efficiency
VR = (((V_s_phase) - (V_r_phase)) / (V_r_phase)) * 100;
% Voltage Regulation

fprintf('--- Short Transmission Line Simulation Results ---\n');
fprintf('Line Impedance (Z): %.2f + j%.2f ohms\n', real(Z), imag(Z));
fprintf('Receiving End Current: %.2f A\n', (I_r_phasor));
fprintf('Sending End Voltage (line-to-line): %.2f kV\n', V_s/1e3);
fprintf('Sending End Power: %.2f MW\n', P_s/1e6);
fprintf('Transmission Efficiency: %.2f %%\n', efficiency);
fprintf('Voltage Regulation: %.2f %%\n', VR);

--- Short Transmission Line Simulation Results ---
Line Impedance (Z): 0.20 + j2.00 ohms
Receiving End Current: 577.35 A
Sending End Voltage (line-to-line): 401.17 kV
Sending End Power: 400.25 MW
Transmission Efficiency: 99.94 %
Voltage Regulation: 0.29 %

```

---

---

*Published with MATLAB® R2024b*