

VIDEO TUTORIAL



i Important!

This replacement procedure can be used for:

BMW 3 Coupe (E92) 318i 2.0, BMW 3 Saloon (E90) 320i 2.0, BMW 3 Saloon (E90) 325i 2.5, BMW 3 Saloon (E90) 330i 3.0, BMW 3 Saloon (E90) 320d 2.0, BMW 3 Saloon (E90) 318i 2.0, BMW 3 Saloon (E90) 318d 2.0, BMW 3 Saloon (E90) 330d 3.0, BMW 3 Saloon (E90) 325xi 2.5, BMW 3 Saloon (E90) 330xi 3.0, BMW 3 Saloon (E90) 330xd 3.0, BMW 3 Saloon (E90) 320si 2.0, BMW 3 Coupe (E92) 335i 3.0, BMW 3 Saloon (E90) 335i 3.0, BMW 3 Coupe (E92) 335d 3.0, (+ 33)

The steps may slightly vary depending on the car design.

REPLACEMENT: TAILGATE STRUTS – BMW E92. TOOLS YOU'LL NEED:



- Multipurpose grease

- Flat Screwdriver

BUY TOOLS

Replacement: tailgate struts – BMW E92. AUTODOC recommends:

- Right and left gas struts of the boot lid should be replaced simultaneously.
- The replacement procedure is identical for the right and left gas struts of the boot lid.
- All work should be done with the engine stopped.


REPLACEMENT: TAILGATE STRUTS – BMW E92. RECOMMENDED SEQUENCE OF STEPS:

1

Open the boot lid.

**2**

Release the circlip connecting the gas strut to the boot lid. Use a flat screwdriver.



3

Release the circlip connecting the gas strut to the car body. Use a flat screwdriver.



Replacement: tailgate struts – BMW E92. AUTODOC experts recommend:

- To avoid any injuries, be sure to hold the boot lid while demounting the gas struts.


4

Remove the boot lid gas strut.




5

Clean the fasteners of the boot lid gas strut.



6

Treat the fasteners of the boot lid gas strut. Use a multipurpose grease.



7

Install the new boot lid gas strut.

Replacement: tailgate struts – BMW E92. Professionals recommend:

- To avoid any injuries, be sure to hold the boot lid while installing the gas strut.

8

Snap on the circlip connecting the gas strut to the boot lid.



9

Snap on the circlip connecting the gas strut to the car body.




10

Check the working condition of the boot lid gas springs after they are installed.



11

Close the lid of the luggage compartment.



WELL DONE! 👍

[VIEW MORE TUTORIALS](#)

AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING



AUTODOC

GET IT ON
Google Play

Download on the
App Store

Download

A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

BUY SPARE PARTS FOR BMW

TAILGATE STRUTS: A WIDE SELECTION