

## SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

### Important!

This replacement procedure can be used for:

BMW 3 Touring (E91) 325i 3.0, BMW 3 Touring (E91) 318d 2.0, BMW 3 Touring (E91) 318i 2.0, BMW 3 Touring (E91) 316d 2.0, BMW 3 Touring (E91) 320i 2.0, BMW 3 Touring (E91) 325i 2.5, BMW 3 Touring (E91) 330i 3.0, BMW 3 Touring (E91) 320d 2.0, BMW 3 Touring (E91) 330d 3.0, BMW 3 Touring (E91) 325xi 2.5, BMW 3 Touring (E91) 330xi 3.0, BMW 3 Touring (E91) 330xd 3.0, BMW 3 Touring (E91) 335i 3.0, BMW 3 Touring (E91) 335d 3.0, BMW 3 Touring (E91) 325d 3.0, (+ 12)

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: BMW 3 Saloon (E90) 318i 2.0

## REPLACEMENT: POLLEN FILTER – BMW 3 TOURING (E91). TOOLS YOU MIGHT NEED:



- Drive socket # 8
- Ratchet wrench
- Fender cover

**Buy tools**

## Replacement: pollen filter – BMW 3 Touring (E91). AUTODOC experts recommend:

- Replace the cabin filter at least once every six months, in early spring and autumn seasons.
- Follow the terms, recommendations and requirements of the part operation provided by the manufacturer.
- If the air flow into the cabin has sharply reduced, replace the filter before a scheduled maintenance.
- Please note: all work on the car – BMW 3 Touring (E91) – should be done with the engine switched off.

## CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:

**1** Open the bonnet.

**2** Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.


**3.1** Unscrew the fasteners of the cabin filter housing cover (6 pieces).



**3.2** Use a drive socket #8. Use a ratchet wrench.



- 4 Remove the cabin filter housing cover.



- 5 Release the cabin filter cover clips.



- 6 Remove the filter element from the filter housing.



### AUTODOC recommends:

- Do not attempt to clean and reuse the filter - it will affect the quality of air cleaning inside the car.

- 7 Insert a new filter element into the filter housing. Make sure that the filter edge fits tight to the housing.



Replacement: pollen filter – BMW 3 Touring (E91). AUTODOC experts recommend:

- Check out the correct location of the filter element. Do not skew.
- Follow the air flow direction arrow on the filter.
- Attention! Use quality filters – BMW 3 Touring (E91).

8

Attach the cabin filter cover clips.



9

Reinstall the cabin filter housing cover.



AUTODOC recommends:

- Replacement: pollen filter – BMW 3 Touring (E91). Do not use excessive force during installation. This may damage the fasteners.

- 10** Screw in the fasteners of the cabin filter housing cover (6 pieces). Use a drive socket #8. Use a ratchet wrench.




- 11** Remove the fender protection cover. Close the hood.



- 12** Switch on the ignition.

- 13** Switch on the air conditioning system. This is necessary in order to make sure that the component operates properly.



- 14** Switch off the ignition.

**WELL DONE!** 

**VIEW MORE TUTORIALS**