

*Heaven's Light is Our Guide*  
**Rajshahi University of Engineering and Technology**



**Course Code**

ECE 3208

**Course Title**

Communication Engineering Sessional

**Experiment Date:** January 21, 2025,

**Submission Date:** February 10, 2025

**Lab Report 3:**

**Determination of Modulation Index of FM Wave**

**Submitted to**

Dr. Md. Kamal Hosain

Professor

Dept of ETE, RUET

**Submitted by**

Md. Tajim An Noor

Roll: 2010025

# Contents

<b>Theory</b>	<b>1</b>
<b>Required Apparatus</b>	<b>2</b>
<b>Block Diagram</b>	<b>2</b>
<b>Procedure</b>	<b>2</b>
<b>Calculations</b>	<b>3</b>
<b>Results</b>	<b>4</b>
<b>Matlab Simulation</b>	<b>4</b>
Code . . . . .	4
<b>Output</b>	<b>6</b>
Experimental Output . . . . .	6
Matlab Output . . . . .	7
<b>Discussion and Conclusion</b>	<b>7</b>
<b>References</b>	<b>7</b>

# Determination of Modulation Index of FM Wave

## Theory

Frequency Modulation (FM) encodes information by varying the instantaneous frequency of a carrier wave, unlike Amplitude Modulation (AM) which varies amplitude. This makes FM more resistant to noise and interference.

The instantaneous frequency of an FM signal is:

$$f(t) = f_c + \Delta f \cdot \sin(2\pi f_m t)$$

where  $f_c$  is the carrier frequency,  $\Delta f$  is the frequency deviation, and  $f_m$  is the modulating signal frequency.

The modulation index ( $\beta$ ) is:

$$\beta = \frac{\Delta f}{f_m}$$

To determine  $\Delta f$ :

### 1. Observe the Modulated Signal:

- Connect the FM modulator output to the oscilloscope.
- Display the frequency spectrum.

### 2. Identify Frequencies:

- Measure the maximum ( $f_{\max}$ ) and minimum ( $f_{\min}$ ) frequencies.

### 3. Calculate Deviation:

- Use  $\Delta f = \frac{f_{\max} - f_{\min}}{2}$ .

The bandwidth ( $B$ ) of an FM signal, according to Carson's rule, is:

$$B \approx 2(\Delta f + f_m) = 2f_m(\beta + 1)$$

FM is widely used in radio broadcasting, TV sound transmission, and two-way radio communication due to its noise immunity and efficient bandwidth use [1, 2].

## Required Apparatus

- ANALOGUE SIGNAL TRANSMISSION DL 3155M60
- Oscilloscope
- Connecting Wires
- Power Supply

## Block Diagram

### FM Modulation and Demodulation

Figure 1: Block Diagram of FM Modulation and Demodulation

## Procedure

1. The FM modulator and demodulator were connected as shown in the block diagram.
2. The message signal was applied to the modulator and the modulated signal was observed on the oscilloscope.
3. The frequency deviation and the modulating frequency were measured from the oscilloscope.
4. The modulation index was calculated using the measured values.
5. The experiment was repeated with different message signals and modulation frequencies to observe their effects.
6. The observed values of frequency deviation, modulating frequency, and modulation index for each experiment were recorded.

## Experimental Data

Reading no	Message Signal's		Modulated Signal's Minimum		Modulated Signal's Maximum	
	Time Period, (s)	Frequency, (kHz)	Time Period, (s)	Frequency, (kHz)	Time Period, (s)	Frequency, (kHz)
1	$1.4 \times 10^{-4}$	7.142	$1.1 \times 10^{-5}$	90.90	$3 \times 10^{-5}$	33.33
2	$1.4 \times 10^{-4}$	7.142	$1.05 \times 10^{-5}$	95.24	$3.3 \times 10^{-5}$	30.3
3	$9 \times 10^{-5}$	11.11	$1.2 \times 10^{-5}$	83.33	$2.5 \times 10^{-5}$	40
4	$2.4 \times 10^{-4}$	3.937	$1.1 \times 10^{-5}$	90.91	$2.4 \times 10^{-5}$	41.67

## Calculations

The modulation index ( $\beta$ ) is calculated using the formula:

$$\beta = \frac{\Delta f}{f_m}$$

where  $\Delta f$  is the frequency deviation and  $f_m$  is the frequency of the message signal. The bandwidth ( $B$ ) of an FM signal can be calculated using Carson's rule:

$$B \approx 2(\Delta f + f_m) = 2f_m(\beta + 1)$$

1. For Reading 1:

$$\begin{aligned} f_m &= 7.142 \text{ kHz} \\ \Delta f &= \frac{90.90 - 33.33}{2} \text{ kHz} = 28.785 \text{ kHz} \\ \beta &= \frac{28.785}{7.142} \approx 4.03 \\ B &\approx 2 \times 7.142 \text{ kHz} \times (4.03 + 1) \approx 71.42 \text{ kHz} \end{aligned}$$

2. For Reading 2:

$$\begin{aligned} f_m &= 7.142 \text{ kHz} \\ \Delta f &= \frac{95.24 - 30.3}{2} \text{ kHz} = 32.47 \text{ kHz} \\ \beta &= \frac{32.47}{7.142} \approx 4.55 \\ B &\approx 2 \times 7.142 \text{ kHz} \times (4.55 + 1) \approx 81.42 \text{ kHz} \end{aligned}$$

3. For Reading 3:

$$\begin{aligned} f_m &= 11.11 \text{ kHz} \\ \Delta f &= \frac{83.33 - 40}{2} \text{ kHz} = 21.665 \text{ kHz} \\ \beta &= \frac{21.665}{11.11} \approx 1.95 \\ B &\approx 2 \times 11.11 \text{ kHz} \times (1.95 + 1) \approx 67.11 \text{ kHz} \end{aligned}$$

4. For Reading 4:

$$\begin{aligned} f_m &= 3.937 \text{ kHz} \\ \Delta f &= \frac{90.91 - 41.67}{2} \text{ kHz} = 24.62 \text{ kHz} \\ \beta &= \frac{24.62}{3.937} \approx 6.25 \\ B &\approx 2 \times 3.937 \text{ kHz} \times (6.25 + 1) \approx 63.50 \text{ kHz} \end{aligned}$$

## Results

The modulation index ( $\beta$ ) and bandwidth ( $B$ ) for each reading are summarized as follows:

- For Reading 1:
  - Modulation Index:  $\beta \approx 4.03$
  - Bandwidth:  $B \approx 71.42$  kHz
- For Reading 2:
  - Modulation Index:  $\beta \approx 4.55$
  - Bandwidth:  $B \approx 81.42$  kHz
- For Reading 3:
  - Modulation Index:  $\beta \approx 1.95$
  - Bandwidth:  $B \approx 67.11$  kHz
- For Reading 4:
  - Modulation Index:  $\beta \approx 6.25$
  - Bandwidth:  $B \approx 63.50$  kHz

## Matlab Simulation

### Code:

```
1  % Parameters
2  fs = 1000;           % Sampling frequency
3  t = 0:1/fs:1;       % Time vector
4  fc = 100;           % Carrier frequency
5  kf = 50;            % Frequency sensitivity
6  Am = 1;             % Amplitude of message signal
7  fm = 10;            % Frequency of message signal
8
9  % Message signal
10 m = Am * cos(2 * pi * fm * t);
11
12 % Carrier signal (square wave)
13 c = square(2 * pi * fc * t);
14
15 % FM Modulation
16 int_m = cumsum(m) / fs; % Integral of message signal
17 s = cos(2 * pi * fc * t + 2 * pi * kf * int_m);
```

```

18
19 % FM Demodulation
20 y = diff([0 s]) * fs;      % Differentiate the FM signal
21 y = abs(hilbert(y));      % Envelope detection
22
23 % Modulation Index
24 beta = kf * Am / fm;
25 disp(['Modulation Index (beta): ', num2str(beta)]);
26
27 % Plotting
28 figure;
29
30 subplot(4,1,1);
31 plot(t, m);
32 title('Message Signal');
33 xlabel('Time (s)');
34 ylabel('Amplitude');
35
36 subplot(4,1,2);
37 plot(t, c);
38 title('Carrier Signal (Square Wave)');
39 xlabel('Time (s)');
40 ylabel('Amplitude');
41
42 subplot(4,1,3);
43 plot(t, s);
44 title('FM Modulated Signal');
45 xlabel('Time (s)');
46 ylabel('Amplitude');
47
48 subplot(4,1,4);
49 plot(t, y(1:length(t)));
50 title('Demodulated Signal');
51 xlabel('Time (s)');
52 ylabel('Amplitude');

```

# Output

## Experimental Output




Figure 2: FM; Yellow: Message, Blue: Modulated Signal 1




Figure 3: FM; Yellow: Message, Blue: Modulated Signal 2




Figure 4: FM; Yellow: Message, Blue: Modulated Signal 3




Figure 5: FM; Yellow: Message, Blue: Modulated Signal 4






Figure 6: Demodulated; Yellow: Message, Blue: Demodulated Signal 1




Figure 8: Demodulated; Yellow: Message, Blue: Demodulated Signal 3




Figure 7: Demodulated; Yellow: Message, Blue: Demodulated Signal 2




Figure 9: Demodulated; Yellow: Message, Blue: Demodulated Signal 4

## Matlab Simulation Output

## Discussion and Conclusion

The modulation index ( $\beta$ ) was found to be crucial in Frequency Modulation (FM) as it determined the bandwidth and the number of significant sidebands. In this experiment,  $\beta$  was calculated for different message signals and modulation frequencies using  $\beta = \frac{\Delta f}{f_m}$ . Significant variations in  $\beta$  (1.95 to 6.25) were observed, impacting the bandwidth and quality of FM signals. The Matlab simulations confirmed the relationship between  $\beta$  and bandwidth, highlighting the importance of selecting an appropriate  $\beta$  for efficient communication. Valuable insights into the effects of  $\beta$  on FM signals and its significance in FM modulation were provided by this experiment.

Matlab simulations confirmed the relationship between  $\beta$  and bandwidth, highlighting the importance of selecting an appropriate  $\beta$  for efficient communication. Valuable insights into the effects of  $\beta$  on FM signals and its significance in FM modulation were provided by this experiment. The results obtained from the experiment and Matlab simulations were consistent, demonstrating the accuracy and reliability of the calculations. Overall, the experiment was successful in determining the modulation index of FM waves and understanding its impact on signal quality and bandwidth.

## References

- [1] S. Haykin, *Communication Systems*. Wiley, 2008.
- [2] J. G. Proakis and M. Salehi, *Digital Communications*. McGraw-Hill, 2007.